

FWC Jerry Can Holder

Installation Instructions

Thank you for choosing Brandner Design's FWC Jerry Can Holder. Below you will find installation instructions and included hardware. You may need a friend to help install.

Hardware Included:

1. Bottom mounting plate screws
 - (15) 1/4-20 x 7/16" hex drive screws
2. Hardware for Rotopax mounting plate
 - (4) 1/4-20 x 1/4" hex drive screws w/ lock washers
3. (2) 6" rubber strips & (2) 8" neoprene strips;
4. (3) Spacers for jack stand mounting plate
5. Jack stand mounting plate hardware
 - (3) 3/8" x 1 1/2" hex head bolts, (3) nylock nuts & washers
6. Under camper mounting hardware
7. Alternative under mount hardware



1. Begin by attaching the bottom mounting plate to the jerry can holder and adhering the rubber & neoprene strips to mounting plates. Rubber strips go on bottom mounting plate; neoprene strips go on back plate.



2. Adhere spacer washers to back mounting plate & remove propane tank if holder will be mounted below propane compartment.



3. Remove jack stand bolts. Existing bolts will not be used again. Place Jerry Can Holder side mount bracket between camper jack stand mount and jack stand mounting bracket. Secure the jerry can holder and jack stand using the new jack stand mounting plate hardware



4. The final step will be securing the bottom mounting plate. Use the bottom mounting plate as a guide for drilling holes through the bottom of the camper. You have a couple options here.

-Use a 5/16" bit if you plan to use a nut and bolt option. Insert the bolt from the top down and secure nut on bottom side of mounting plate.

-Use a 1/8" bit for pilot hole if you plan to use a lag bolt option. Fasten lag bolt from the bottom mounting plate into the camper base.

